CDX-A15

SERVICE MANUAL

US Model
Canadian Model
AEP Model
E Model



SPECIFICATIONS

System
Compact disc digital audio system
Laser diode properties
Material: GaAlAs
Wavelength: 780 nm
Emission duration: Continuous
Laser output power: Less than 44.6 μW*
* This output is the value measured at a distance of 200 mm from the objective lens surface on the Optical Pick-up Block.
D-A conversion
16-bit linear
Frequency response
5 - 20,000 Hz ±1 dB
Signal-to-noise ratio
90 dB
Wow and flutter
Below measurable limit
Outputs
Line output (for changer connector only)

General
Current drain
800 mA (CD playback)
800 mA (during disc loading or eject)
Operating temperature
−10°C - 55°C (14°F - 131°F)
Mounting dimensions
Approx. 301 × 98 × 200 mm (w/h/d)
(11 7/8 × 3 7/8 × 7 7/8 in.)
not incl. projecting parts and controls
Weight
Approx. 3 kg (6 lb 10 oz)
Supplied accessories
Disc magazine (1)
Mounting hardware (1 set)
Extension cord (1)
Optional accessory
Compact disc single adaptor CSA-8

Design and specifications subject to change without notice.

FEATURES

- **Mobile CD auto changer** automatically changes the discs in the disc magazine and enables you to play the desired selections of the 10 discs.
- **Compact and space-saving** for either vertical or horizontal installation in the car.
- The connected equipment enables you to operate the changer in the car.
- High quality sound obtained with the 4 fs digital filter.

COMPACT DISC PLAYER

SONY®

TABLE OF CONTENTS

Section	Title	Page
	Specifications	1
	Features	1
1.	SERVICING NOTES	
	Notes on Handling the Optical Pick-up Block or Base Unit	2
	Protection of Eyes from Laser Beam during Servicing	3
2.	GENERAL	
	Preparations	4
	Installation	4
	Connections	4
3.	DISASSEMBLY	6
4.	MECHANICAL ADJUSTMENTS	
	Large Elevator Gear Position (Location 10.5) Adjustment	7
	Homing Adjustment	8
5.	ELECTRICAL ADJUSTMENTS	
	1. Focus Offset Adjustment	9
	2. Tracking Offset Adjustment	9
	3. Tracking Gain Adjustment	10
	4. Focus Gain Adjustment	11
	5. PLL Freerun Frequency Adjustment	11
6.	DIAGRAMS	
6-1.	IC503 CX7991 Pin Function Description	12
6-2.	RF Printed Wiring Board	13
6-3.	Other Printed Wiring Boards	18
6-4.	Schematic Diagram	23
7.	EXPLODED VIEWS	28
8.	ELECTRICAL PARTS LIST	34
	Mounting Hardwares	37

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK ⚠ OR DOTTED LINE WITH MARK ⚠ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SECTION 1
SERVICING NOTES

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.

During repair, pay attention to electrostatic breakdown and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE ⚠ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

PROTECTION OF EYES FROM LASER BEAM DURING SERVICING

This set employs a laser. Therefore, be sure to follow carefully the instructions below when servicing.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

1. Laser Diode Properties
   - Material: GaAlAs
   - Wavelength: 780 nm
   - Emission Duration: continuous
   - Laser Output: max. 44.6 μW*

     * This output is the value measured at a distance of about 200 mm from the objective lens surface on the Optical Pick-up Block.

2. During service, do not take the Optical Pick-up Block apart, and do not adjust the APC circuit. If there is a breakdown in the APC circuit (including laser diode), replace the entire Optiocal Pick-up Block (including APC borad).

BESKYTTELSE AF ØJNE MOD LASERSTRÅLING UNDER SERVICE

I dette apparat anvendes laserlys. Derfor skal nedenstående instruktioner nøje følges under service.

Følg iøvrigt instruktionerne i servicemanualen.

ADVARSEL!!

Under service må øjnene ikke komme nær objektiv-linsen på den optiske pick-up enhed. I tilfælde af at det er nødvendigt at kontrollere udsendelsen af laserlys, skal det ske i en afstand af mere end 25 cm fra den optiske pick-up.

1. Laser-didoe data
   - Materiale: GaAlAs
   - Bølgelængde: 780 nm
   - Udstråling: Kontinuerlig
   - Laseroutput: Max. 0,4 mW*

     * Målt i 1,6 mm afstand fra overfladen af objektivlinsen på den optiske pick-up enhed.

   - Klassifikation: Klasse IIIb.

2. Adskil aldrig den optiske pick-up enhed under service, og juster ikke APC kredsløbet (Automatic Power Control). Hvis APC kredsløbet (incl. laserdioden) bryder ned, skal hele den optiske pick-up enhed (incl. APC printkortet) udskiftes.

LASER ADVARSEL MÆRKNING

Følgende mærkning findes indvendig i apparatet:

1. Advarsel Mærkning


CAUTION : INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.
ADVARSEL : USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSAFBRYDERE ER UDE AF FUNKTION UNDGÅ UDSÆTTELSE FOR STRÅLING.
4 885 843 02

VAROITUS: Laite sisältää, laserdiodin, joka lähettää (näkymätöntä) silmille vaarallista lasersateilyä.

SECTION 2 GENERAL

PREPARATIONS
PREPARATIFS
VORBEREITUNGEN
PREPARATIVOS
准备

1



2



3



4



Use the unit with the door closed
Otherwise, foreign matter may enter the unit, and contaminate the lens in the player.

Note
To play a 8 cm CD, use the Sony CSA-8 adaptor (not supplied). Playing a 8 cm CD without the adaptor may damage the unit.

Utiliser cet appareil avec la porte fermée
Si cela n'est pas fait, des matières étrangères peuvent entrer dans l'appareil et contaminer l'objectif du lecteur.

Remarque
Pour la lecture de disque compact de 8 cm, utiliser l'adaptateur Sony CSA-8 (non fourni). Sans lui, l'appareil risque d'être endommagé.

Das Gerät nur mit geschlossener Tür betreiben
Halten Sie die Tür des Gerätes stets geschlossen, damit keine Fremdkörper in das Geräteinnere gelangen und die Linse im Spieler verschmutzen können.

Hinweis
Verwenden Sie zur Wiedergabe einer 8-cm-CD den Sony Adapter CSA-8 (Sonderzubehör). Wiedergabe einer 8-cm-CD ohne Adapter kann zur Beschädigung des Gerätes führen.

Emplee la unidad con la puerta cerrada
De lo contrario, podrían introducirse materias extrañas y contaminar el objetivo del reproductor.

Nota
Para reproducir un disco compacto de 8 cm., utilice el adaptador CSA-8 Sony (no suministrada). La reproducción de un disco compacto de 8 cm. sin el adaptador puede dañar la unidad.

使用时请关上唱片匣室门

否则易让异物夹杂入于机内，或使唱机的透镜蒙上灰尘。

注

播放8cm唱片时，请另使用一个Sony CSA-8型大孔唱片固定器。

播放8cm唱片时若不使用该唱片固定器，会致使唱机损毁。

SUPPLIED MOUNTING HARDWARE
MATERIEL DE MONTAGE FOURNI
MITGELIEFERTE BEFESTIGUNGSTEILE
FERRETERÍA DE MONTAJE SUMINISTRADA
附属的安装用道具



INSTALLATION

PRECAUTIONS

- Choose the mounting location carefully, observing the following:
  —The fuel tank should not be damaged by the tapping screws.
  —There should be no wire harnesses nor pipelines under the place where you are going to install the unit.
  —The spare tire, tools or other equipment in or under the trunk should not be interfered with nor damaged by the screws or the unit itself.
- Be sure to use only the supplied mounting hardware for a safe and secure installation.

HOW TO INSTALL THE UNIT

To install the unit horizontally

1



2



To install the unit vertically

1



2



Be sure to reposition the spring as shown in the illustration above.

INSTALLATION

PRECAUTIONS

- Choisir soigneusement l'endroit de montage en observant ce qui suit.
  —Le réservoir d'essence ne doit pas être endommagé par les vis taraudeuses.
  —Il ne doit pas y avoir de faisceau de fils ou de tuyaux sous l'endroit où l'on désire installer l'appareil.
  —La roue de secours, les outils ou autre équipement dans ou sous le coffre ne doivent pas être gênés ni endommagés par les vis ou l'appareil lui-même.
- S'assurer d'utiliser uniquement le matériel de montage fourni pour une installation correcte et sûre.

INSTALLATION DE L'APPAREIL

Installation de l'appareil à l'horizontale

3



4



5



Installation de l'appareil à la verticale

3



4



5



Ne manquer pas de remettre le ressort comme illustré ci-dessus.

INSTALLATION

ZUR BESONDEREN BEACHTUNG

- Bei der Wahl des Einbauortes ist folgendes zu beachten:
  —Der Tank darf durch die Blechschrauben nicht beschädigt werden.
  —Unter der Fläche, auf die das Gerät montiert werden soll, dürfen sich keine Drähte oder Rohrleitungen befinden.
  —Ersatzreifen, Werkzeug usw. dürfen durch die Blechschrauben nicht beschädigt werden. Achten Sie auch darauf, daß die Herausnahme des Ersatzreifens, Werkzeugs usw. nicht durch das Gerät behindert wird.
- Für sicheren und stabilen Einbau verwenden Sie ausschließlich die mitgelieferten Befestigungsteile.

INSTALLATION DES GERÄTES

Zur horizontalen Aufstellung

3

4

5

Zur vertikalen Aufstellung

3

4

5

Versetzen Sie die Feder wie oben abgebildet.

INSTALACIÓN

PRECAUCIONES

- Elija cuidadosamente el lugar de montaje, teniendo en cuenta lo siguiente:
  —El depósito de combustible no deberá dañarse con los tornillos roscachapa.
  —No deberá haber mazos de conductores ni tubos debajo del lugar donde vaya a instalar la unidad.
  —La rueda de repuesto, las herramientas, u otros equipos situados dentro o debajo del portaequipajes no deberán verse interferidos ni dañados por los tornillos ni por la propia unidad.
- Para realizar una instalación segura, emplee solamente la ferretería de montaje suministrada.

INSTALACIÓN DE LA UNIDAD

Instalación horizontal de la unidad

3

4

5

Instalación vertical de la unidad

3

4

5

Asegúrese de reponer el resorte como muestra la ilustración superior.

安装

使用前须知事项

- 安装以前请参照下列事项，仔细选择安装位置：
  —不可让自攻螺钉伤及油箱。
  —唱机不可安装在电线配线或暖气管上面。
  —唱机安装位置或螺钉等不可妨碍或伤及备用轮胎、汽车修理工具或其他汽车零件。
- 为保安全及牢固起见，安装时请使用附属的安装用道具。

如何安装

水平安装法

垂直安装法

切记须按照上图所示，把弹簧拉回原处。

CONNECTIONS
CONNEXIONS
ANSCHLUSS
CONEXIONES
电线之连接

Sony cassette car stereo with the function to control the CD changer
Autostéréo à cassette Sony possédant la fonction de contrôler le changeur de disque compact
Sony Auto-Stereo-Anlage mit Steuermöglichkeit für CD-Spieler-Wechslereinheit.
Reproductor estéreo Sony del automóvil con la función de control del combiador de discos compactos
至附有唱片转换控制功能的SONY汽车收录两用机



Caution
Before making connections, disconnect the ground wire terminal of the car battery to avoid short circuits.

Note
Be sure to use the **supplied** extension cord. Using a cord other than supplied one may cause noise.

For details, refer to the installation/connection manual of each product.

Attention
Avant d'effectuer les connexions, déconnecter le fil de masse de la batterie de voiture pour éviter un court-circuit.

Remarque
Sassurer d'utiliser le cordon de rallongement **fourni**. D'autre cordons risqueraient de causer du bruit.

Pour plus de détails, se reporter au mode d'emploi pour l'installation/connexion de chaque produit.

Achtung
Zur Vermeidung von Kurzschlüssen trennen Sie vor dem Anschließen den Erdungsanschluß der Autobatterie ab.

Hinweis
Achten Sie darauf, stets das **mitgelieferte** Verlängerungskabel zu verwenden. Bei Verwendung eines anderen Kabels können Störgeräusche auftreten.

Einzelheiten entnehmen Sie der Installations/Anschluß-Anleitung des betreffenden Geräts.

Precaución
Antes de realizar las conexiones, desconecte el terminal del conductor de puesta a carrocería de la batería del automóvil para evitar cortocircuitos.

Nota
Asegúrese de utilizar el cable de extensión **suministrado**. Si usa otro cable que no sea el suministrado, puede producirse ruido.

Con respecto a los detalles, consulte el manual de instalación/conexión de cada producto.

注意

连接以前请先拔下汽车电池的接地线，以免发生短路。

注

务必使用附属的延长用电线。若使用其他电线会引起噪音。

详细请参看各个机件的安装/连接使用说明书。

SECTION 3
DISASSEMBLY

CASE

After removing the bottom case, remove the front panel ass'y.



UPPER CASE



ON ASSEMBLING

First, assemble the bottom case, and next, the front panel ass'y.



SECTION 4
MECHANICAL ADJUSTMENTS

[LARGE ELEVATOR GEAR POSITION (LOCATION 10.5) ADJUSTMENT]

1. Move the middle elevator gear in the arrowed direction and place the top plate at the position where there are no clearances between the bottom face of the top plate and the top edges of the three claws.



Fig. 1

2. Put the large elevator gear on the shaft of the top plate taking care not to move the middle elevator gears. The large elevator gear should be fastened by the top plate and EHS protrusion and should position in the relationship with the EHS as shown in Fig. 1.
3. After the placing, fix the large elevator gear with a retaining ring.





Edge of EHS protrusion and edge of protrusion on the large elevator gear should be aligned as shown.

Fig. 2

[HOMING ADJUSTMENT]

Note: 1. The mechanism section should be completely assembled.

2. Control the mechanism with the main unit XR-7300.



Fig. 3

1. Put the disk magazine containing several disks in the changer.
2. Initialize the changer.
3. Pull off the first disk.
4. Wait until the elevator lowers down to the home position.
5. Move the large elevator gear so that the clearance between the inner edge face of the chucking plate and edge of the top face of the stainless chuck-holding plate becomes in 1.5 mm (1/16 inches) as shown in Fig. 4.
6. Make a dot marking on the large elevator gear as shown in Fig. 5.
7. Re-put the first disk in the disk magazine.
8. Pull off the first disk again. The dot marking made in the step 6 above should position as shown in Fig. 5.
9. Fine adjust the position of the large elevator gear with the home-position adjustment screw shown in Fig. 3.

Adjustment Screw Position	Large Elevator Gear Position Displacement
One (1) turn in clockwise	15 (fifteen) degrees clockwise
One (1) turn in counterclockwise	15 (fifteen) degrees counterclockwise



Fig. 4



Note:
Make a marking near and on the center line of the EHS sensor.

Fig. 5

SECTION 5
ELECTRICAL ADJUSTMENTS

1. Perform adjustments as given.
2. Be sure to use the disc "YEDS-18" parts code: 3-702-101-01, but only when indicated.
3. Unsolder the small shield plate from the RF board.
4. Power supply voltage: DC 14.4 V (more than 2A).

1. Focus Offset Adjustment

Procedure:



1. Connect the oscilloscope to RF board test point [EYE].
2. Put the set into play mode by loading the disc.
3. Adjust main board RV2 so that the oscilloscope waveform eye pattern is good.
   A good eye pattern means that the diamond shape (◊) in the center of the oscilloscope can be clearly distinguished.

Volt/Div: 200 mV
Time/Div: 0.5 µSec



2. Tracking Offset Adjustment

Procedure:



1. Connect the oscilloscope to RF board test point [TRGA], pin (1) of IC1.
2. Put the set into play mode by loading the disc.
3. Press the |◀◀ or ▶▶| (or ◀◀ , ▶▶) button, then check the traverse waveform*.
4. Adjust RV1 (main board) so that oscilloscope reading is symmetrical in relation to 0 V.

*Traverse waveform: This is the tracking error waveform appears when crossing the track.

Volt/Div: 0.5 V
Time Div: 2 mSec
Center 0 V



traverse wafeform
(100 track jump waveform)

3. Tracking Gain Adjustment (coarse adjustment)

This adjustment is to be performed when replacing the following parts.

- Optical Pick-up Block
- RV4

This adjustment should be performed after focus offset and tracking offset adjustments are completed.

Procedure:



1. Connect the oscilloscope to RF board test point TRGA.
2. Put the set into play mode by loading the disc.
3. Turn RF board RV4 from clockwise stop, then check the oscilloscope waveform.
   Fix RV4 at the position where the waveform disappears.

Volt/Div: 0.5 V
Time/Div: 2 mSec



waveform when the wave appears



waveform when the wave disappeared

- **When gain is lowered . . .**
  When selecting by pressing |◀◀ or ▶▶| button, brake application is poor because of low tracking gain. Therefore, the traverse waveform appears after the 100 track jump waveform, then the selection will be located slowly.



- **When gain is highered . . .**
  Operation noise is heard due to a scratch or dust, then operation will be instability.



RV3 standard position

4. Focus Gain Adjustment (coarse adjustment)

This adjustment is to be performed when replacing the following parts.

- Optical Pick-up Block
- RV3

Procedure:

1. Set RV3 (RF board) to the standard position.
2. Check that there is not an abnormal amount of operation noise (white noise) from the 2-axis devise. If there is, turn RV3 slightly clockwise.





- **When gain is highered . . .**
  The set does not play because of no focus operation.
- **When gain is highered . . .**
  Operation noise is heard due to a scratch or a dust, then operation will be unstable.

5. PLL Freerun Frequency Adjustment

Procedure:

1. Unsolder the solder bridge at Ⓐ.
   (IC3 pin ⑤ is opened)
2. Connect 100 kΩ resistors to Ⓑ, Ⓒ.
   (This is to set the IC3 pin ⑪ voltage to 2.5 V)
3. Install a test jumper wire between Ⓓ and Ⓔ on the jack board to pull up the P/C terminal of the DC-DC converter ⊖.
4. Connect the frequency counter to RF board test point PLCK (IC3 pin ⑦⓪).
5. Turn the power switch on (Do not use the disc), then adjust RV5 so that the frequency is 4.3218 MHz ±10 kHz.
6. After adjusting, reset 1, 2 and 3 as original.





[JACK BOARD] – Conductor Side –



SECTION 6
DIAGRAMS

6-1. IC503 CX7991 PIN FUNCTION DESCRIPTION

Pin No.	Description
1 – 8	Parallel output terminal. The internal register status is loaded and output using a strobe signal. When a set signal is input, "1" is output. When a reset signal is input, "0" is output.
9, 11 – 13	Parallel output terminal. The internal register status is loaded and output using a strobe signal. When a set or reset signal is input, the output becomes high impedance. The output is then enabled using a strobe signal.
10	GND
14	Serial data output terminal.
15	Set signal input terminal. Becomes active when low. When this pin is set low, the latch is set and "1" is output to pins 1 through 8 irrespective of the internal register status. Pins 9, 11, 12, and 13 then becomes high impedance.
16	Reset signal input terminal. Becomes active when low. When this pin is set low, the latch is reset and "0" is output to pins 1 through 8 irrespective of the internal register status. Pins 9, 11, 12, and 13 then becomes high impedance.
17	Strobe signal input terminal. Becomes active when high. When this pin is set high, the internal register status is shifted to the latch status.
18	Serial data input terminal. The external serial data is input.
19	Clock signal input terminal. Data is loaded when the system is initiated.
20	Power supply

6-2. RF PRINTED WIRING BOARD

- **See pages 21 to 23 for Schematic Diagram.**
- **See page 26 for Semiconductor Lead Layouts.**

Note:

- ○——: parts extracted from the component side.
- ●——: parts extracted from the conductor side.
- ●: Through hole.
- ▒: Pattern on the side which is seen.
- ▒: Pattern of the rear side.

• Semiconductor Location

Ref. No.	Location
D1	F-14
IC1	E-10
IC2	G-10
IC3	G-12
IC4	F-15
IC5	E-7
IC6	H-14
IC7	F-13
IC301	E-12
IC302	D-12
IC303	E-14
IC304	D-17
Q1	D-11
Q2	F-8
Q3	F-8
Q4	F-8
Q5	F-7
Q6	F-14
Q8	E-14
Q9	H-11
Q10	G-11
Q101	E-15
Q201	E-15
Q301	D-16
Q302	D-16



• IC BLOCK DIAGRAMS

IC1 CXA-1081Q



IC2 CXA1082Q



IC3 CXD1125Q



IC5 LA6530



IC7 CXD1316DM



IC301 CXD1161M-2



IC501, 507 LB1649



IC502 S-8054HN-CB



IC503 CX-7991



6-3. OTHER PRINTED WIRING BOARDS

- See pages 13 to 15 for RF Printed Wiring Board.
- See pages 29 to 30 for Semiconductor Lead Layouts.

Note:
- ○—— : parts extracted from the component side.
- ●—— : parts extracted from the conductor side.

- Semiconductor Location

Ref. No.	Location	Ref. No.	Location
D301	D-15	Q303	C-5
D302	E-5	Q304	D-5
D303	C-14	Q305	C-14
D304	C-13	Q401	J-28
D401	E-27	Q402	E-27
D402	J-28	Q403	C-21
D403	G-21	Q502	G-6
D404	G-21	Q505	D-6
D405	G-20	Q506	D-6
D501	D-11	Q511	F-9
D502	E-10	Q512	F-10
D503	F-9	Q513	F-9
D505	F-9	Q514	F-10
D507	G-11	Q515	E-9
D508	G-8	Q516	G-10
D509	D-11	Q517	F-9
D511	F-8	Q518	F-10
D512	F-8	Q519	F-8
D513	F-9	Q520	F-8
D514	E-8	Q523	G-15
D515	H-8	Q524	G-15
D516	F-8	Q704	E-13
D518	F-8	Q705	C-13
D703	D-13	Q706	D-13
D704	D-13	Q707	D-9
D705	C-8	Q710	D-12
D706	F-13		
D707	D-12		
D708	D-14		
D709	F-14		
D710	D-8		
IC501	D-10		
IC502	H-5		
IC503	D-7		
IC505	F-7		
IC507	E-12		





Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and ¼ W or less unless otherwise specified.

Note:	Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- ▭▭▭ : B + Line.
- ▭▭▭ : B – Line.
- ▭ : adjustment for repair.
- Power voltage is dc 14.4 V and fed with regurated dc power supply from CNP501.
- Voltages and waveforms are dc with respect to ground under no-signal conditions.
- Voltages are taken with a VOM (10 MΩ/V). Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to wavefroms.
- **Signal path.**
  ▷ : CD
- **On voltage measurement, RF board ground should be connected to the chassis ground.**

• WAVEFORMS

❶ IC505 pin ⑱



❷ IC7 pin ①



❸ IC2 pin ⑭, IC3 pin ③



❹ IC3 pin ④



❺ IC3 pin ⑧



❻ IC7 pin ⑬



❼ IC1 pin ⑭



❽ IC2 pin ⑫



❾ IC1 pin ㉒

❿ IC1 pin ①



⓫ Q2, 3 emitter

SECTION 7
EXPLODED VIEWS

NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- Due to standardization, parts with part number suffix -XX and -X may be different from the parts specified in the components used on the set.
- Color Indication of Appearance Parts Example:
  (RED) . . . KNOB, BALANCE (WHITE)
  ↑ ↑
  Cabinet's Color Parts' Color

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

(1)



No.	Part No.	Description	Remarks
1	X-3331-918-1	PANEL ASSY, FRONT	
2	*3-348-742-02	BRACKET (O DAMPER LEFT)	
3	3-355-772-01	DAMPER (OIL)	
4	3-348-584-01	SPRING (FLOATING), TENSION	
5	3-333-069-51	COVER (LEFT), SIDE	
6	X-3331-919-1	CASE ASSY, UPPER	
7	3-831-441-11	CUSHION	
8	3-333-070-51	COVER (RIGHT), SIDE	
9	*3-360-714-01	BRACKET (CONNECTOR RETAINER)	
10	*3-360-717-01	(US,AEP,E).....LABEL, MODEL NUMBER	
	*3-360-718-01	(CANADIAN).....LABEL, MODEL NUMBER	
	*3-360-719-01	(GERMANY).....LABEL, MODEL NUMBER	
11	3-355-750-01	CASE (BOTTOM)	
12	*3-348-726-01	PLATE (VA), SHIELD	
13	*3-333-066-01	SHEET (LARGE), INSULATING	
14	3-348-750-01	CUSHION (DAMPER)	
15	7-682-147-09	SCREW +P 3X6	
16	*3-348-743-01	BRACKET (O DAMPER RIGHT)	
17	7-682-546-09	SCREW +B 3X5	
18	7-685-133-19	SCREW +BTP 2.6X6 TYPE2 N-S	
19	3-348-749-01	WASHER (TEFLON)	
20	7-621-770-87	SCREW +BVTT 2.6X5 (S)	
21	*3-343-739-01	PLATE, PROTECTION, FLEXIBLE	
22	*3-348-765-01	PLATE (SMALL), SHIELD	
23	*3-348-766-01	PLATE (SA), SHIELD	
24	*3-348-764-01	PLATE (RF), SHIELD	
25	*4-885-838-00	(AEP).....LABEL, CLASS 1	
26	*3-333-067-01	TAG	
27	3-360-715-01	DOOR, FRONT	
901	*A-3265-019-A	MOUNTED PCB, RF	
902	*A-3265-026-A	MOUNTED PCB, JACK	
916	1-623-641-11	PC BOARD, RF FLEXIBLE	
917	1-623-642-11	PC BOARD, TRANSLATION FLEXIBLE	
918	1-575-938-11	CORD (WITH CONNECTOR)	

(2)



No.	Part No.	Description	Remarks
51	3-343-724-01	ESCUTCHEON	
52	3-343-712-01	BUTTON, EJECT	
53	3-331-916-01	GEAR (MIDDLE), ELEVATOR	
54	*3-333-082-01	RETAINER, SCREW, FEED	
55	3-343-708-01	ROLLER, MAGAZINE	
56	*3-343-711-01	SHAFT, ROLLER, MAGAZINE	
57	3-343-710-11	SPRING	
58	7-624-102-04	STOP RING 1.5, TYPE -E	
59	3-343-709-01	SPRING	
60	7-621-775-00	SCREW +B 2.6X3	
61	3-331-907-01	RETAINER, SCREW, FEED	
62	3-331-952-01	GEAR (LARGE), ELEVATOR	
63	3-343-707-01	GEAR (SMALL), ELEVATOR	
64	7-682-544-04	SCREW +P 3X3	
65	4-917-404-01	GEAR, MOTOR	
66	7-621-255-10	SCREW +P 2X3	
67	3-831-441-11	CUSHION	
68	*3-343-714-01	BRACKET, FOP	
70	3-333-081-01	BEARING (UPPER & LOWER)	
71	*X-3329-567-1	PLATE ASSY, TOP	
72	7-621-775-20	SCREW +BVTT 2.6X5 (S)	
73	7-621-255-25	SCREW +BVTT 2X4 (S)	
74	7-685-103-19	SCREW +P 2X5 TYPE2 NON-SLIT	
75	7-685-132-19	SCREW +P 2.6X5 TYPE2 NON-SLIT	
76	7-627-553-17	PRECISION SCREW +P 2X2 TYPE 3	
77	7-624-118-01	RING, RETAINING E-2.5	
78	3-568-749-00	CUSHION, ECM	
79	*3-348-767-01	SPRING (MOTOR GROUND)	
80	*3-343-741-01	PLATE, GROUND	
910	1-622-793-11	PC BOARD, EHS	
913	1-622-796-11	PC BOARD, EJECT	
C701	1-136-165-00	CAP, METALIZED FILM 0.1MF	
M3	1-541-309-11	MOTOR, L (RF-370C)	

(3)



No.	Part No.	Description	Remarks
101	*3-333-092-01	BRACKET (S), PHOTO	
102	3-329-560-01	SCREW, M6	
103	*3-329-570-01	PLATE, SCREW	
104	X-3329-554-1	SCREW ASSY, FEED	
105	7-621-772-40	SCREW +B 2X8	
106	3-329-558-01	BEARING, MAIN ROLLER	
107	3-323-231-02	ROLLER (LOWER)	
108	X-3329-520-1	SHAFT (LOWER) ASSY, ROLLER	
109	3-329-553-01	SPRING, E	
110	3-321-813-11	WASHER, COTTER POLYETHYLENE	
111	3-329-555-11	GEAR (E), R	
112	*X-3329-522-1	LEVER ASSY, R	
113	*3-333-006-01	REINFORCEMENT	
114	7-621-770-67	SCREW +B 2.6X6	
115	3-362-867-01	SPACER (D)	
116	3-329-551-01	METAL (B), SHAFT	
117	*X-3329-565-1	CHASSIS ASSY, E	
118	7-685-132-19	SCREW +P 2.6X5 TYPE2 NON-SLIT	
119	*3-331-944-01	LEVER, SLIDE	
120	3-329-547-01	ROLLER, IDLE	
121	3-331-943-01	GEAR (F), R	
122	7-624-102-04	STOP RING 1.5, TYPE -E	
123	7-621-255-10	SCREW +P 2X3	
124	3-333-099-01	GEAR (A)	
125	3-895-818-01	WASHER, POLYETHYLENE, COTTER	
126	3-343-701-01	GEAR (B)	
127	3-831-441-11	CUSHION	
128	3-571-823-00	SPRING, TENSION	
129	3-333-098-01	SHAFT, DISK CHUCK	
131	3-535-369-XX	SPRING, TENSION	
132	3-343-718-01	BRACKET, DISK CHUCK	
133	3-343-717-01	PLATE (M), CHUCK	
135	7-621-255-25	SCREW +BVTT 2X4 (S)	
136	7-621-775-20	SCREW +BVTT 2.6X5 (S)	
137	7-624-104-04	STOP RING 2.0, TYPE -E	
907	1-622-790-11	PC BOARD, M1	
908	1-622-791-11	PC BOARD, CB	
909	1-622-792-11	PC BOARD, DPT	
911	1-622-794-11	PC BOARD, DDE	
912	1-622-795-11	PC BOARD, LED	
915	1-634-606-11	PC BOARD, FLEXIBLE	
M2	X-3329-560-1	MOTOR ASSY, M2	

• SEMICONDUCTOR LEAD LAYOUTS



(4)



No.	Part No.	Description	Remarks
151	3-547-665-11	SPRING, TENSION	
152	7-624-102-04	STOP RING 1.5, TYPE -E	
153	3-310-958-00	WASHER (R)	
154	3-343-706-01	LINK, DISK	
155	*3-331-925-01	BEARING, ROLLER STOPPER	
156	*X-3329-517-1	LEVER (F) ASSY, LINK	
157	3-323-231-02	ROLLER (LOWER)	
158	X-3329-518-1	ROLLER (UPPER) ASSY	
159	*3-329-552-01	SHAFT, SIDE ROLLER	
160	*X-3329-516-1	LEVER (B) ASSY, LINK	
161	X-3329-561-1	SHAFT (UPPER) ASSY, ROLLER	
162	3-331-924-01	GEAR (G), ROLLER	
163	3-331-914-01	GEAR, ROLLER 3 STEP	
164	3-331-957-06	GUIDE, DISK	

(5)



No.	Part No.	Description	Remarks
201	*X-3323-201-1	CHASSIS ASSY, PACK	
202	7-621-255-65	+BVTT 2X10 (S)	
203	7-624-102-04	STOP RING 1.5, TYPE -E	
204	X-3329-513-1	GEAR ASSY, CAM	
205	7-624-104-04	STOP RING 2.0, TYPE -E	
206	3-331-905-01	ROLLER (A)	
207	*X-3329-507-1	LEVER ASSY, LINEAR	
208	3-331-927-01	ROLLER, LINEAR LEVER	
209	3-568-315-01	SPRING, COMPRESSION	
210	X-3329-558-1	SLIDER ASSY, LINEAR	
211	3-331-904-01	SHAFT, LINEAR SLIDER	
212	3-329-580-01	ROLLER, CAM	
213	*X-3329-510-1	LEVER ASSY, SLIDER SET	
214	3-333-088-01	WHEEL, WORM	
215	X-3329-557-1	GEAR ASSY	
216	X-3329-511-1	LEVER ASSY, SOFT EJECT	
217	3-331-951-01	GEAR (2), EJECT CAM	
218	3-333-087-01	HOOK, BACK LOCK	
219	*3-331-913-01	EJECTOR (2), SOFT	
220	3-343-723-01	SPRING, TENSION	

No.	Part No.	Description	Remarks
221	3-634-191-XX	SPRING, TENSION	
222	*3-329-573-01	SHAFT, LOCK HOOK	
223	7-628-253-90	SCREW +PS 2.6X4	
224	3-535-369-XX	SPRING, TENSION	
226	3-831-441-11	CUSHION	
227	*X-3329-555-1	OPENER ASSY (A)	
228	*3-333-084-01	SHAFT (B), FIXED, E	
229	*3-333-083-01	SHAFT (A), FIXED, E	
230	*3-343-715-01	PLATE, FIXED, MOTOR	
231	7-621-775-00	SCREW +P 2.6X3	
232	*X-3329-556-1	OPENER ASSY (B)	
233	*X-3329-568-1	CHASSIS ASSY, BOTTOM	
235	7-682-546-09	SCREW +B 3X5	
237	7-621-775-20	SCREW +B 2.6X5	
903	1-617-989-13	PC BOARD, H.M	
904	1-622-787-11	PC BOARD, LOT	
905	1-622-788-11	PC BOARD, P.S	
906	1-622-789-11	PC BOARD, E.J	
914	1-622-797-11	PC BOARD, TRANSLATION	
917	1-623-642-11	PC BOARD, TRANSLATION FLEXIBLE	

(6) OPTICAL PICK-UP BLOCK (KSM-160BAN)



No.	Part No.	Description	Remarks
301	7-685-104-19	SCREW +P 2X6 TYPE2 NON-SLIT	
302	X-2640-611-1	RETAINER ASSY, THRUST	
303	3-321-813-01	WASHER, COTTER POLYETHYLENE	
304	2-640-625-02	GEAR (B)	
305	7-627-553-37	PRECISION SCREW +P 2X3 TYPE 3	
306	2-640-620-03	SCREW (B) (1.4X3), TAPPING	
307	2-640-632-01	SHAFT, GUIDE	
308	2-640-645-01	RETAINER, GUIDE SHAFT	
309	7-685-102-19	SCREW +P 2X4 TYPE2 NON-SLIT	
310	2-640-623-01	COVER, MD	
311	7-627-852-17	+P 1.7X4	
312	2-640-654-03	GUIDE (D), FEED	
313	A-4910-196-A	SCREW BLOCK ASSY, SLED MD	
315	2-640-617-02	SPRING, COMPRESSION	
316	2-640-650-02	STOPPER, RING	
317	3-367-580-01	RING, CENTER	
318	7-627-451-17	SCREW, PRECISION +K 1.4X2.5	
919	⚠8-848-067-01	PICKUP, OPTICS KSS-160B	
920	1-630-551-11	PC BOARD, ML2 FLEXIBLE	
M902	A-4910-100-B	GEAR ASSY, SLED MOTOR	
S902	1-554-938-11	SWITCH, LEAF	

Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Note:
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

SECTION 8
ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- Items marked "★" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- If there are two or more same circuits in a set such as a stereophonic machine, only typical circuit parts may be indicated and capacitors and resistors in other same circuits may be omitted.

CAPACITORS:
MF: μF, PF: μμF.

RESISTORS
- All resistors are in ohms.
- F: nonflammable

COILS
- MMH: mH, UH: μH

SEMICONDUCTORS
In each case, U: μ, for example:
UA...: μA..., UPA...: μPA...,
UPC...: μPC, UPD...: μPD...

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No.	Part No.	Description			
901	*A-3265-019-A	MOUNTED PCB, RF			
902	*A-3265-026-A	MOUNTED PCB, JACK			
903	1-617-989-13	PC BOARD, H.M			
904	1-622-787-11	PC BOARD, LOT			
905	1-622-788-11	PC BOARD, P.S			
906	1-622-789-11	PC BOARD, E.J			
907	1-622-790-11	PC BOARD, M1			
908	1-622-791-11	PC BOARD, CB			
909	1-622-792-11	PC BOARD, DPT			
910	1-622-793-11	PC BOARD, EHS			
911	1-622-794-11	PC BOARD, DOE			
912	1-622-795-11	PC BOARD, LED			
913	1-622-796-11	PC BOARD, EJECT			
914	1-622-797-11	PC BOARD, TRANSLATION			
915	1-634-606-11	PC BOARD, FLEXIBLE			
916	1-623-641-11	PC BOARD, RF FLEXIBLE			
917	1-623-642-11	PC BOARD, TRANSLATION FLEXIBLE			
918	1-575-938-11	CORD (WITH CONNECTOR)			
919	⚠8-848-067-01	PICKUP, OPTICAL KSS-160B			
920	1-630-551-11	PC BOARD, ML2 FLEXIBLE			
C1	1-163-078-11	CERAMIC CHIP	0.033MF	10%	25V
C2	1-126-177-11	ELECT	100MF	20%	6.3V
C3	1-163-078-11	CERAMIC CHIP	0.033MF	10%	25V
C4	1-163-059-00	CERAMIC CHIP	0.01MF	10%	50V
C5	1-126-177-11	ELECT	100MF	20%	6.3V
C6	1-126-154-11	ELECT	47MF	20%	6.3V
C7	1-124-442-00	ELECT	330MF	20%	6.3V
C8	1-163-062-00	CERAMIC CHIP	0.018MF	10%	50V
C9	1-126-177-11	ELECT	100MF	20%	6.3V
C10	1-124-465-00	ELECT	0.47MF	20%	50V
C11	1-163-059-00	CERAMIC CHIP	0.01MF	10%	50V
C12	1-163-062-00	CERAMIC CHIP	0.018MF	10%	50V
C13	1-164-161-11	CERAMIC CHIP	0.0022MF	10%	50V
C14	1-163-077-00	CERAMIC CHIP	0.1MF	10%	25V
C15	1-163-077-00	CERAMIC CHIP	0.1MF	10%	25V
C16	1-124-442-00	ELECT	330MF	20%	6.3V
C17	1-124-442-00	ELECT	330MF	20%	6.3V
C18	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C19	1-126-162-11	ELECT	3.3MF	20%	35V
C20	1-163-077-00	CERAMIC CHIP	0.1MF	10%	25V
C21	1-163-077-00	CERAMIC CHIP	0.1MF	10%	25V
C22	1-163-105-00	CERAMIC CHIP	33PF	5%	50V
C23	1-163-077-00	CERAMIC CHIP	0.1MF	10%	25V
C24	1-163-809-11	CERAMIC CHIP	0.047MF	10%	25V

Ref.No.	Part No.	Description			
C25	1-124-257-00	ELECT	2.2MF	20%	50V
C26	1-163-076-00	CERAMIC CHIP	0.068MF		50V
C27	1-126-177-11	ELECT	100MF	20%	6.3V
C28	1-126-177-11	ELECT	100MF	20%	6.3V
C29	1-127-558-11	ELECT(SOLID)	10MF	20%	6.3V
C30	1-163-037-11	CERAMIC CHIP	0.022MF	10%	25V
C31	1-163-017-00	CERAMIC CHIP	0.0047MF	10%	50V
C32	1-163-078-11	CERAMIC CHIP	0.033MF	10%	25V
C33	1-124-465-00	ELECT	0.47MF	20%	50V
C34	1-126-154-11	ELECT	47MF	20%	6.3V
C35	1-163-141-00	CERAMIC CHIP	0.001MF	5%	50V
C36	1-124-442-00	ELECT	330MF	20%	6.3V
C37	1-126-160-11	ELECT	1MF	20%	50V
C38	1-126-160-11	ELECT	1MF	20%	50V
C39	1-127-558-11	ELECT(SOLID)	10MF	20%	6.3V
C40	1-163-105-00	CERAMIC CHIP	33PF	5%	50V
C41	1-163-105-00	CERAMIC CHIP	33PF	5%	50V
C44	1-163-077-00	CERAMIC CHIP	0.1MF	10%	25V
C47	1-163-141-00	CERAMIC CHIP	0.001MF	5%	50V
C48	1-124-442-00	ELECT	330MF	20%	6.3V
C49	1-124-442-00	ELECT	330MF	20%	6.3V
C50	1-127-558-11	ELECT(SOLID)	10MF	20%	6.3V
C51	1-124-987-11	ELECT	3300MF	20%	6.3V
C52	1-124-987-11	ELECT	3300MF	20%	6.3V
C53	1-124-442-00	ELECT	330MF	20%	6.3V
C55	1-163-097-00	CERAMIC CHIP	15PF	5%	50V
C56	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C58	1-126-160-11	ELECT	1MF	20%	50V
C59	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C60	1-164-232-11	CERAMIC CHIP	0.01MF	10%	50V
C100	1-163-101-00	CERAMIC CHIP	22PF	5%	50V
C101	1-163-038-00	CERAMIC CHIP	0.1MF		25V
C102	1-163-137-00	CERAMIC CHIP	680PF	5%	50V
C103	1-163-139-00	CERAMIC CHIP	820PF	5%	50V
C104	1-163-113-00	CERAMIC CHIP	68PF	5%	50V
C105	1-163-063-00	CERAMIC CHIP	0.022MF	10%	50V
C106	1-124-638-11	ELECT	22MF	20%	6.3V
C107	1-163-191-00	CERAMIC CHIP	270PF	5%	50V
C150	1-124-638-11	ELECT	22MF	20%	6.3V
C200	1-163-101-00	CERAMIC CHIP	22PF	5%	50V
C201	1-163-038-00	CERAMIC CHIP	0.1MF		25V
C202	1-163-137-00	CERAMIC CHIP	680PF	5%	50V
C203	1-163-139-00	CERAMIC CHIP	820PF	5%	50V
C204	1-163-113-00	CERAMIC CHIP	68PF	5%	50V
C205	1-163-063-00	CERAMIC CHIP	0.022MF	10%	50V

Ref.No.	Part No.	Description			
C206	1-124-638-11	ELECT	22MF	20%	6.3V
C207	1-163-191-00	CERAMIC CHIP	270PF	5%	50V
C250	1-124-638-11	ELECT	22MF	20%	6.3V
C301	1-124-442-00	ELECT	330MF	20%	6.3V
C302	1-124-463-00	ELECT	0.1MF	20%	50V
C303	1-124-463-00	ELECT	0.1MF	20%	50V
C304	1-124-463-00	ELECT	0.1MF	20%	50V
C305	1-124-463-00	ELECT	0.1MF	20%	50V
C306	1-101-005-00	CERAMIC	0.022MF		25V
C307	1-124-464-11	ELECT	0.22MF	20%	50V
C308	1-124-464-11	ELECT	0.22MF	20%	50V
C501	1-136-742-11	FILM	0.1MF	5%	50V
C502	1-136-742-11	FILM	0.1MF	5%	50V
C503	1-124-455-00	ELECT	100MF	20%	16V
C505	1-163-055-00	CERAMIC CHIP	0.0047MF	10%	50V
C506	1-126-157-11	ELECT	10MF	20%	6.3V
C507	1-124-225-00	ELECT	100MF	20%	6.3V
C508	1-163-063-00	CERAMIC CHIP	0.022MF	10%	50V
C511	1-126-160-11	ELECT	1MF	20%	50V
C512	1-124-465-00	ELECT	0.47MF	20%	50V
C513	1-136-742-11	FILM	0.1MF	5%	50V
C542	1-124-455-00	ELECT	100MF	20%	16V
C543	1-136-742-11	FILM	0.1MF	5%	50V
C546	1-127-558-11	ELECT(SOLID)	10MF	20%	6.3V
C547	1-125-486-11	DOUBLE LAYERED	0.22F		5.5V
C548	1-136-742-11	FILM	0.1MF	5%	50V
C549	1-124-229-00	ELECT	33MF	20%	6.3V
C551	1-163-077-00	CERAMIC CHIP	0.1MF		50V
C552	1-136-742-11	FILM	0.1MF	5%	50V
C701	1-136-165-00	CAP, METALIZED FILM	0.1MF		
C703	1-126-160-11	ELECT	1MF	20%	50V
C705	1-163-063-00	CERAMIC CHIP	0.022MF	10%	50V
C706	1-126-247-11	ELECT	560MF	20%	6.3V
C707	1-126-247-11	ELECT	560MF	20%	6.3V
C710	1-124-119-00	ELECT	330MF	20%	16V
C718	1-126-157-11	ELECT	10MF	20%	6.3V
C719	1-124-229-00	ELECT	33MF	20%	6.3V
C720	1-124-755-00	ELECT	3300MF	20%	16V
C721	1-163-063-00	CERAMIC CHIP	0.022MF	10%	50V
CN301	1-506-914-11	PIN, CONNECTOR 2P			
CNJ1	*1-566-776-11	SOCKET, CONNECTOR 12P			
CNJ2	*1-568-509-11	HOUSING, CONNECTOR 11P			
CNJ4	*1-566-887-11	SOCKET, CONNECTOR 18P			
CNJ401	*1-566-887-11	SOCKET, CONNECTOR 18P			
CNJ402	1-562-719-11	SOCKET, CONNECTOR 10P			
CNJ501	*1-569-725-11	PIN, CONNECTOR (PC BOARD) 18P			
CNJ502	*1-566-887-11	SOCKET, CONNECTOR 18P			
CNJ503	*1-566-887-11	SOCKET, CONNECTOR 18P			
CNJ504	1-562-631-11	SOCKET, CONNECTOR 4P			
CNP201	*1-566-001-11	PIN, CONNECTOR (PC BOARD) 4P			
CNP401	*1-506-984-11	PIN, CONNECTOR (PC BOARD) 2P			
CNP402	*1-506-984-11	PIN, CONNECTOR (PC BOARD) 2P			
CNP403	*1-506-984-31	PIN, CONNECTOR (PC BOARD) 2P			
CNP404	*1-506-985-11	PIN, CONNECTOR (PC BOARD) 3P			
CNP405	*1-506-985-11	PIN, CONNECTOR (PC BOARD) 3P			
CNP406	*1-506-988-11	PIN, CONNECTOR (PC BOARD) 6P			

Ref.No.	Part No.	Description
CNP408	1-506-481-11	PIN, CONNECTOR 2P
CNP409	1-506-467-11	PIN, CONNECTOR 2P
CNP410	1-506-467-11	PIN, CONNECTOR 2P
CNP411	*1-506-998-11	PIN, CONNECTOR (PC BOARD) 2P
CNP412	*1-506-999-11	(EHS BOARD)..PIN, CONNECTOR(PC BOARD)3P
CNP412	1-506-467-11	(HOME SW BOARD)...PIN, CONNECTOR 2P
D1	8-719-104-34	DIODE 1S2836
D301	8-719-976-19	DIODE RLS-4148
D302	8-719-400-18	DIODE MA152WK
D303	8-719-911-19	DIODE 1SS119
D304	8-719-400-18	DIODE MA152WK
D401	8-719-812-31	DIODE TLR123
D402	8-719-812-31	DIODE TLR123
D403	8-719-104-34	DIODE 1S2836
D404	8-719-104-34	DIODE 1S2836
D405	8-719-104-34	DIODE 1S2836
D501	8-719-110-12	DIODE RD9.1ES-B1
D502	8-719-109-98	DIODE RD6.2ES-B2
D503	8-719-104-34	DIODE 1S2836
D505	8-719-104-34	DIODE 1S2836
D507	8-719-109-85	DIODE RD5.1ES-B2
D508	8-719-911-19	DIODE 1SS119
D509	8-719-110-35	DIODE RD13ES-B1
D511	8-719-109-85	DIODE RD5.1ES-B2
D512	8-719-109-85	DIODE RD5.1ES-B2
D513	8-719-109-85	DIODE RD5.1ES-B2
D514	8-719-109-85	DIODE RD5.1ES-B2
D515	8-719-109-85	DIODE RD5.1ES-B2
D516	8-719-109-85	DIODE RD5.1ES-B2
D518	8-719-911-19	DIODE 1SS119
D703	8-719-976-19	DIODE RLS-4148
D704	8-719-910-62	DIODE HZ6A2L
D705	8-719-109-93	DIODE RD6.2EB2
D706	8-719-109-85	DIODE RD5.1ES-B2
D707	8-719-110-48	DIODE RD18ES-B1
D708	8-719-976-19	DIODE RLS-4148
D709	8-719-109-85	DIODE RD5.1ES-B2
D710	8-719-976-19	DIODE RLS-4148
DD1	1-464-848-31	CONVERTER UNIT, DC-DC
IC1	8-752-033-14	IC CXA1081Q
IC2	8-752-032-32	IC CXA1182Q-Z
IC3	8-752-332-38	IC CXD1125Q
IC4	8-759-981-37	IC MB88505H-1023M
IC5	8-759-821-58	IC LA6530
IC6	8-752-323-65	IC CXK5816M-15L
IC7	8-759-946-27	IC CXD1316DM
IC301	8-759-805-33	IC CXD1161M-2
IC302	8-759-100-96	IC UPC4558G2
IC303	8-759-981-99	IC RC4560M
IC304	8-759-981-99	IC RC4560M
IC501	8-759-802-32	IC LB1649
IC502	8-759-940-45	IC S-8054HN-CB-S
IC503	8-757-991-00	IC CX-7991
IC505	8-759-112-05	IC UPD7508HG-593-22
IC507	8-759-802-32	IC LB1649

Ref.No.	Part No.	Description			
JR1	1-216-295-00	METAL GLAZE	0	5%	1/10W
JR2	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR401	1-216-295-00	METAL GLAZE	0	5%	1/10W
JR402	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR403	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR404	1-216-295-00	METAL GLAZE	0	5%	1/10W
JR550	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR551	1-216-296-00	METAL GLAZE	0	5%	1/8W
JR552	1-216-296-00	METAL GLAZE	0	5%	1/8W
L1	1-410-501-11	INDUCTOR	2.2UH		
L3	1-410-501-11	INDUCTOR	2.2UH		
L4	1-410-316-11	INDUCTOR	1UH		
L7	1-410-196-11	INDUCTOR CHIP	2.2UH		
L8	1-410-196-11	INDUCTOR CHIP	2.2UH		
L10	1-410-501-11	INDUCTOR	2.2UH		
L11	1-410-196-11	INDUCTOR CHIP	2.2UH		
L101	1-410-196-11	INDUCTOR CHIP	2.2UH		
L201	1-410-196-11	INDUCTOR CHIP	2.2UH		
L301	1-410-196-11	INDUCTOR CHIP	2.2UH		
L501	1-410-501-11	INDUCTOR	2.2UH		
L504	1-410-501-11	INDUCTOR	2.2UH		
L505	1-410-501-11	INDUCTOR	2.2UH		
L506	1-410-501-11	INDUCTOR	2.2UH		
L507	1-410-501-11	INDUCTOR	2.2UH		
M1	X-3329-571-2	MOTOR ASSY			
M2	X-3329-560-1	MOTOR ASSY, M2			
M3	1-541-309-11	MOTOR, L (RF-370C)			
M902	A-4910-100-B	GEAR ASSY, SLED MOTOR			
Q1	8-729-106-60	TRANSISTOR 2SB1115A			
Q2	8-729-106-60	TRANSISTOR 2SB1115A			
Q3	8-729-106-68	TRANSISTOR 2SD1615A-GP			
Q4	8-729-106-60	TRANSISTOR 2SB1115A			
Q5	8-729-106-68	TRANSISTOR 2SD1615A-GP			
Q6	8-729-901-00	TRANSISTOR DTC124EK			
Q8	8-729-271-22	TRANSISTOR 2SC2712G			
Q9	8-729-900-53	TRANSISTOR DTC114EK			
Q10	8-729-901-01	TRANSISTOR DTC144EK			
Q101	8-729-202-38	TRANSISTOR 2SC3326N			
Q201	8-729-202-38	TRANSISTOR 2SC3326N			
Q301	8-729-901-05	TRANSISTOR DTA124EK			
Q302	8-729-901-00	TRANSISTOR DTC124EK			
Q303	8-729-113-69	TRANSISTOR FN1F4M-M32			
Q304	8-729-901-00	TRANSISTOR DTC124EK			
Q305	8-729-901-00	TRANSISTOR DTC124EK			
Q401	8-729-110-21	TRANSISTOR PH102			
Q402	8-729-110-21	TRANSISTOR PH102			
Q403	8-719-906-43	DIODE GP-1S03			
Q502	8-729-216-22	TRANSISTOR 2SA1162			
Q505	8-729-216-22	TRANSISTOR 2SA1162			
Q506	8-729-216-22	TRANSISTOR 2SA1162			
Q511	8-729-113-69	TRANSISTOR FN1F4M-M32			
Q512	8-729-901-00	TRANSISTOR DTC124EK			
Q513	8-729-113-69	TRANSISTOR FN1F4M-M32			
Q514	8-729-271-23	TRANSISTOR 2SC2712-G			
Q515	8-729-113-69	TRANSISTOR FN1F4M-M32			
Q516	8-729-271-23	TRANSISTOR 2SC2712-G			
Q517	8-729-113-69	TRANSISTOR FN1F4M-M32			
Q518	8-729-901-00	TRANSISTOR DTC124EK			

Ref.No.	Part No.	Description			
Q519	8-729-901-00	TRANSISTOR DTC124EK			
Q520	8-729-113-69	TRANSISTOR FN1F4M-M32			
Q523	8-729-271-22	TRANSISTOR 2SC2712-G			
Q524	8-729-113-69	TRANSISTOR FN1F4M-M32			
Q704	8-729-901-00	TRANSISTOR DTC124EK			
Q705	8-729-106-60	TRANSISTOR 2SB1115A			
Q706	8-729-271-22	TRANSISTOR 2SC2712G			
Q707	8-729-106-68	TRANSISTOR 2SD1615A-GP			
Q710	8-729-900-53	TRANSISTOR DTC114EK			
R1	1-216-081-00	METAL GLAZE	22K	5%	1/10W
R2	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R3	1-216-151-00	METAL GLAZE	11	5%	1/8W
R4	1-216-151-00	METAL GLAZE	11	5%	1/8W
R5	1-216-049-00	METAL GLAZE	1K	5%	1/10W
R6	1-216-057-00	METAL GLAZE	2.2K	5%	1/10W
R7	1-216-076-00	METAL GLAZE	13K	5%	1/10W
R8	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R9	1-216-074-00	METAL GLAZE	11K	5%	1/10W
R10	1-216-105-00	METAL GLAZE	220K	5%	1/10W
R11	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R12	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R13	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R14	1-216-109-00	METAL GLAZE	330K	5%	1/10W
R15	1-216-093-00	METAL GLAZE	68K	5%	1/10W
R16	1-216-099-00	METAL GLAZE	120K	5%	1/10W
R17	1-216-117-00	METAL GLAZE	680K	5%	1/10W
R18	1-216-071-00	METAL GLAZE	8.2K	5%	1/10W
R19	1-216-107-00	METAL GLAZE	270K	5%	1/10W
R20	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R21	1-216-061-00	METAL GLAZE	3.3K	5%	1/10W
R22	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R23	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R24	1-216-080-00	METAL GLAZE	20K	5%	1/10W
R25	1-216-121-00	METAL GLAZE	1M	5%	1/10W
R27	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R28	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R29	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R40	1-216-024-00	METAL GLAZE	91	5%	1/10W
R41	1-216-049-00	METAL GLAZE	1K	5%	1/10W
R42	1-216-081-00	METAL GLAZE	22K	5%	1/10W
R43	1-216-049-00	METAL GLAZE	1K	5%	1/10W
R44	1-216-230-00	METAL GLAZE	22K	5%	1/8W
R45	1-216-001-00	METAL GLAZE	10	5%	1/10W
R50	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R51	1-214-804-11	METAL	3.3	1%	1/2W
R52	1-216-077-00	METAL GLAZE	15K	5%	1/10W
R53	1-216-138-00	METAL GLAZE	3.3	5%	1/8W
R55	1-216-049-00	METAL GLAZE	1K	5%	1/10W
R56	1-216-049-00	METAL GLAZE	1K	5%	1/10W
R58	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R100	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R101	1-216-288-11	METAL GLAZE	5.6M	5%	1/8W
R102	1-216-680-11	METAL CHIP	16K	0.50%	1/10W
R103	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R104	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R105	1-216-679-11	METAL CHIP	15K	0.50%	1/10W
R106	1-216-657-11	METAL CHIP	1.8K	0.50%	1/10W

Ref.No.	Part No.	Description			
R107	1-216-001-00	METAL GLAZE	10	5%	1/10W
R108	1-216-643-11	METAL CHIP	470	0.50%	1/10W
R109	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R110	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W
R112	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R113	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
R114	1-216-675-11	METAL CHIP	10K	0.50%	1/10W
R115	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R200	1-216-651-11	METAL CHIP	1K	0.50%	1/10W
R201	1-216-288-11	METAL GLAZE	5.6M	5%	1/8W
R202	1-216-680-11	METAL CHIP	16K	0.50%	1/10W
R203	1-216-683-11	METAL CHIP	22K	0.50%	1/10W
R204	1-216-691-11	METAL CHIP	47K	0.50%	1/10W
R205	1-216-679-11	METAL CHIP	15K	0.50%	1/10W
R206	1-216-657-11	METAL CHIP	1.8K	0.50%	1/10W
R207	1-216-150-00	METAL GLAZE	10	5%	1/8W
R208	1-216-643-11	METAL CHIP	470	0.50%	1/10W
R209	1-216-113-00	METAL GLAZE	470K	5%	1/10W
R210	1-216-065-00	METAL GLAZE	4.7K	5%	1/10W
R212	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R213	1-216-677-11	METAL CHIP	12K	0.50%	1/10W
R214	1-216-675-11	METAL CHIP	10K	0.50%	1/10W
R215	1-216-627-11	METAL CHIP	100	0.50%	1/10W
R301	1-216-039-00	METAL GLAZE	390	5%	1/10W
R304	1-216-097-00	METAL GLAZE	100K	5%	1/10W
R305	1-216-198-00	METAL GLAZE	1K	5%	1/8W
R307	1-216-150-00	METAL GLAZE	10	5%	1/8W
R308	1-216-150-00	METAL GLAZE	10	5%	1/8W
R401	1-216-182-00	METAL GLAZE	220	5%	1/8W
R402	1-216-182-00	METAL GLAZE	220	5%	1/8W
R403	1-216-033-00	METAL GLAZE	220	5%	1/10W
R502	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R503	1-249-429-11	CARBON	10K	5%	1/4W
R505	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R506	1-216-214-00	METAL GLAZE	4.7K	5%	1/8W
R507	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R508	1-216-073-00	METAL GLAZE	10K	5%	1/10W
R516	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R518	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R519	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R520	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R521	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R530	1-216-182-00	METAL GLAZE	220	5%	1/8W
R531	1-249-417-11	CARBON	1K	5%	1/4W
R532	1-247-903-00	CARBON	1M	5%	1/4W
R533	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R534	1-216-246-00	METAL GLAZE	100K	5%	1/8W
R535	1-216-246-00	METAL GLAZE	100K	5%	1/8W
R536	1-216-246-00	METAL GLAZE	100K	5%	1/8W
R537	1-216-246-00	METAL GLAZE	100K	5%	1/8W
R540	1-249-437-11	CARBON	47K	5%	1/4W
R541	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R542	1-216-222-00	METAL GLAZE	10K	5%	1/8W
R543	1-249-417-11	CARBON	1K	5%	1/4W
R544	1-216-025-00	METAL GLAZE	100	5%	1/10W
R545	1-216-025-00	METAL GLAZE	100	5%	1/10W
R704	1-216-198-00	METAL GLAZE	1K	5%	1/8W

Ref.No.	Part No.	Description			
R705	1-216-206-00	METAL GLAZE	2.2K	5%	1/8W
R706	1-216-238-00	METAL GLAZE	47K	5%	1/8W
R707	1-216-190-00	METAL GLAZE	470	5%	1/8W
R708	1-216-206-00	METAL GLAZE	2.2K	5%	1/8W
R709	1-216-198-00	METAL GLAZE	1K	5%	1/8W
R710	1-216-238-00	METAL GLAZE	47K	5%	1/8W
R711	1-216-206-00	METAL GLAZE	2.2K	5%	1/8W
R713	1-214-792-00	METAL	1	1%	1/2W
RV1	1-228-995-00	RES, ADJ, CARBON 22K			
RV2	1-230-633-41	RES, ADJ, CARBON 47K			
RV3	1-228-995-00	RES, ADJ, CARBON 22K			
RV4	1-228-995-00	RES, ADJ, CARBON 22K			
RV5	1-228-991-00	RES, ADJ, CARBON 2.2K			
RY300	1-515-614-11	RELAY			
S901	1-554-938-11	SWITCH, LEAF (LIMIT)			
SW101	1-554-813-41	SWITCH, KEY BOARD (EJECT)			
SW102	1-570-503-11	SWITCH, MICRO (CBP)			
SW103	1-570-502-11	SWITCH, MICRO (M1)			
SW104	1-570-504-11	SWITCH, MICRO (HOME)			
SW105	1-570-504-11	SWITCH, MICRO (LOT)			
SW106	1-570-504-11	SWITCH, MICRO (PST)			
SW107	1-570-504-11	SWITCH, MICRO (EJECT)			
TH1	1-807-776-11	THERMISTOR ERT-D2FHJ802T			
TH2	1-807-776-11	THERMISTOR ERT-D2FHJ802T			
THP501	1-807-368-11	THERMISTOR PTH59F04BG222TS			
X2	1-567-820-11	VIBRATOR, CRYSTAL 16MHz			
X501	1-567-775-11	VIBRATOR, CERAMIC 4.19MHz			

ACCESSORY & PACKING MATERIAL

	1-575-681-12	CORD (WITH CONNECTOR)
*	3-343-733-01	CUSHION (LOWER)
*	3-343-734-01	CUSHION (UPPER)
*	3-360-704-01	INDIVIDUAL CARTON
	3-751-844-11	(CANADIAN, AEP, E, GERMANY)..... MANUAL, INSTRUCTION (ENGLISH, FRENCH GERMAN, SPANISH, CHINESE)
	3-751-844-21	(US)....MANUAL, INSTRUCTION (ENGLISH)
	3-751-844-41	(AEP)...MANUAL, INSTRUCTION (DUTCH, SWEDISH, ITALIAN, PORTUGUESE)
	X-2114-001-1	HOLDER ASSY, CD BOOKLET
	X-3331-906-1	MAGAZINE ASSY

MOUNTING HARDWARE

401	X-3329-570-1	SCREW ASSY
402	X-3329-574-1	BRACKET ASSY
403	3-354-608-01	BRACKET (CHANGER)



English
93L05028-1(2)
Printed in Japan
© 1991. 1

Sony Corporation
Mobile Electronics Group

9-955-868-13
(Including 9-955-868-91)

Published by Audio Sector Quality Assurance Dept.